Op-amps are versatile elements used to implement various circuits such as amplifiers, comparators, filters, and son on. In this experiment, you become familiar with a typical op-amp and its common applications.

MANDATORY EXPERIMENTS

Experiment 1

Build the circuit shown in Fig. 1 using an op-amp comparator module. Create a pair of ± 18 V voltages and connect them to the supply connectors of the module.




Figure 1: An op-amp as a comparator.

- (a) Set $V_{s1}=0$ or equivalently, connect the inverting input of the op-amp to the ground. Apply a 1-V 1-kHz sine voltage $v_{s2}(t)$ to the non-inverting input. Watch the the output voltage and the non-inverting input voltage of the op-amp simultaneously on the oscilloscope. Interpret the results. Change the sine wave to a triangle wave and observe the results.
- (b) Set $V_{s1} = \pm 0.5$ V and repeat the previous part.
- (c) Swap the input voltages to the op-amp and redo the previous parts.

Experiment 2

Build the circuit shown in Fig. 2 using an op-amp comparator module. Create a pair of ± 18 V voltages and connect them to the supply connectors of the module as well as to the fixed legs of the potentiometer.




Figure 2: An op-amp as a comparator along with a potentiometer as a voltage divider.

(a) Apply a 1-V 1-kHz sine voltage $v_{s2}(t)$ to the non-inverting input. Watch the the output voltage and the non-inverting input voltage of the op-amp simultaneously on the oscilloscope. Turn the knob of the potentiometer and observe the results.

(b) Repeat the previous part for a triangle wave.

Experiment 3

Build the circuit shown in Fig. 3 using an op-amp inverting amplifier module. Create a pair of ± 18 V voltages and connect them to the supply connectors of the module.




Figure 3: Inverting amplifier.

(a) Apply a 0.5-V 1-kHz sine voltage $v_s(t)$ to the input of the amplifier. Watch the the output and input voltages of the amplifier simultaneously on the oscilloscope. Calculate the gain of the amplifier.

	1	b)	Devise an ex	operiment to	measure the in	put and out	put resistance	of the am	plifier modu	ıle
--	---	----	--------------	--------------	----------------	-------------	----------------	-----------	--------------	-----

(c) Increase the amplitude of the input 1-kHz sine wave and record your observations. Interpret and discuss the results.

(d) Increase the frequency of the input 0.5-V sine wave and record your observations. Interpret and discuss the results.

Experiment 4

Build the circuit shown in Fig. 4 using an op-amp non-inverting amplifier module. Create a pair of ± 18 V voltages and connect them to the supply connectors of the module.




Figure 4: Non-inverting amplifier.

(a) Apply a 0.5-V 1-kHz sine voltage $v_s(t)$ to the input of the amplifier. Watch the the output and input voltages of the amplifier simultaneously on the oscilloscope. Calculate the gain of the amplifier.

(b) Measure the input and output resistance of the amplifier module experimentally.

(c) Increase the amplitude of the input 1-kHz sine wave and record your observations. Interpret and discuss the results.

(d) Increase the frequency of the input 0.5-V sine wave and record your observations. Interpret and discuss the results.

Experiment 5

Cascade an inverting amplifier and a non-inverting amplifier as shown in Fig. 5.




Figure 5: Cascade of two amplifiers.

(a) Apply a 100-mV 1-kHz sine voltage $v_s(t)$ to the input of the cascaded amplifiers. Watch the the output and input voltages of the cascaded amplifiers simultaneously on the oscilloscope. Calculate the overall gain of the cascaded amplifiers.

(b) Swap the order of the amplifiers and repeat the previous part. Is there any difference between the measured gains in the two experiments? Explain.

BONUS EXPERIMENTS

Experiment 6

In a circuit design, we need to cascade an inverting and a non-inverting amplifier to get the overall gain of $G_{tot}=G_{inv}G_{nnv}$.

(a) From analytical point of view, is there any difference to change the order of the cascaded amplifiers?

(b) From practical point of view, is there any difference to change the order of the cascaded amplifiers? Justify your answer using PSpice simulation.

Experiment 7

Op-amps usually need a pair of positive and negative DC supply voltages $\pm V_s$.

(a) What happens if the absolute values of the supply voltages differ?

(b) Is it possible to use an op-amp with the supply voltages 0 and $+V_s$? Explain.

Experiment 8

Return your work report by filling the LaTeXtemplate of the manual. Include useful and high-quality images to make the report more readable and understandable.

